


Complete informations on this form will enable us to design the best professional sail for Your boat.
 If You have old sail, You can send it to us, or complete the measurement form of existing jib, You can find it on our website. If it's possible send us IRC or ORC certificate.
 If any dimension is unclear to You, see the technical drawing included to the form.

Name, Surname:	Boat model:	Phone, eMail:
----------------	-------------	---------------

Type of sail:
 Inshore
 Offshore
 Racing


- 1 (cross cut)
- 2 (radial cut)
- 3 (membran sail)

Optional - preferred material:



dimension „I”	Height of foretriangle. Measured from deck level (not mast step) along the forward edge of the mast to the intersection of the forestay and mast.	
dimension „J”	Base of the foretriangle. Measured from the front of the mast horizontally to the intersection of the forestay and deck.	
Maximum luff	Maximum distance between tack shackle (tack point) to the swivel shackle (head point). Fix the measurer edge to the jib halyard and hoist it maximum to the top.	
Maximum foot	<ol style="list-style-type: none"> 1. Fix the rope (or measurer if You have two) to the jib halyard. 2. Hoist it maximum to the top. 3. Fix measurer to the tack shackle (tack point). 4. Place the rope (from point „1”) toward the jib track until the measurer slightly touches spreader or the lower diagonal shroud. Rope touch: <div style="text-align: center; margin: 5px 0;"> spreader shroud </div> <ol style="list-style-type: none"> 5. Place the traveler on that point. 6. Measure (with measurer from point „3”) distance from tack shackle (tack point) to upper part of the clew traveler. 	

Tack point fitting type



longitudinal



trasversal



closed loop




hook




snap shackle

Forestay diameter



Dimensions has to be reported from the „0”. Use measurer with point zero on the outside edge.



The yacht deck is not perfectly straight. Provide the difference between forestay attachment point and the shrouds attachment point to the water line. This dimension is called the sheer line	
M. dimension is difference between mast step and deck	

Dimension from head point (with halyard hoisted maximum to the top) to front (D1) and end (D2) edge of clew traveler	D1	D2
Dimension from forestay attachment point to front (E1) and end (E2) edge of clew traveler	E1	E2
Dimension from boat centerline to front (F1) and end (F2) edge of clew traveler	F1	F2
Clew traveler on the deck on the roof of the cabin	If the clew travelers are on the roof of the cabin, how much higher than deck	

Notes (add Your special needings for Your sail):